



# HANDLE BANNERS CAREFULLY NOT TO KINK OR CREASE!

\*\*\*Warranty does not cover the mishandling and/or damaging of graphic panels!

- ① Assemble each BannerMate ~ 1 Graphic and 1 Banner Stand as per Single Unit instructions provided. Align each stand in a straight line.
- ② To join stands together: Slide WHITE alignment rods in the top and bottom rails of connecting stands.  
\*\*NOTE: These MUST be installed before connecting banners together. WHITE alignment rods at top and bottom of connecting stands will allow for correct alignment when connecting stands together.
- ③ Make sure banners are touching, install (3) Flexi-Mag alignment channel bars per banner connection to secure panel seams.
- ④ Repeat Step #3 to the other outer banner stand.





①



③



## Step ② - Joining Stands Together



Slide alignment rods at top and bottom of connecting stands. This will align and help provide a connection across the joints of the banner stands.

Floor must be level or the graphic panel may not align perfectly

2013

affordable  
**exhibit**  
displays inc

**STORAGE TIP!** Roll banners image side out and place in tube, pole and chrome weighted base go in last.

800.723.2050 • 207.782.6175 • Fax 783.9685  
www.affordabledisplays.com  
email sales@affordabledisplays.com