



# BOOST SET-UP INSTRUCTIONS



Flip the Base upside down and rotate the feet to sit perpendicular to the Base.



Insert the Shock Corded Pole into the hole in the center of the Base. Ensure the pole is seated completely into the bottom half circle cutout.



Stand facing the back of the Base and gently pull the Banner Rail upwards. Slide the clip into the opening of the Banner Rail.



## Tips for raising & lowering banner into base:

- Be sure to hold top of banner tightly and not let go!
- Center banner into base to not damage banner edges!

V. 01/19

## Warranty Information:

The Boost banner stand hardware & pole are covered under a 1 year warranty. Custom printed banner is covered for 90 days from order date. This warranty does not apply if the product has been damaged due to misuse and abuse, altered or used in ways or purposes it was not designed, or which have been damaged in shipping transit.