

Ripple Media screen holder

For media screen with VESA 75/100 or our iPad holder (80029)

Item no. IS-9835

Please observe: We do **not** recommend using a media screen holder on a single free-standing banner stand section.



A Push the top and bottom knob into the center and remove the screen holder.



B Mount the screen holder at your screen or iPad holder.



1 Remove the top post and replace it with the media screen holder without the black holder (see photo instruction A).




2 Build up the complete wall and attach the graphic panels.



3 Mount the screen (see photo instruction B) and then push the screen holder into the post holder while at the same time pressing the two buttons on the post holder together.

Graphic measurement



Make a 70 x 140 mm / 2.75 x 5.5" hole in the center of and 420 mm / 16.6" from the top.