

Single Case Podium Instructions

PODIUM COMPONENTS



Bottom black kick plate

Graphic wrap

Podium top

Instructions for both
shipping case

Item #CASSRM38 Item #CASSRM42



1. Set cases in place angled the way you'd like it to remain for the duration

2. LOOSELY wrap bottom black kick plate around bottom of cases and secure with velcro at back side of podium, press to engage velcro

3. With Graphic wrap still rolled start connecting around case


– Be sure to line up just below top of cases. To Install -

Starting at one end, unroll slowly attaching the graphic magnetically to the bottom kick plate as you go. It's recommended to note where the cases meet and use as a center guide for the location of your graphic to prevent unnecessary adjustments.

4. Fasten Graphic in back with velcro Press on edges to engage Velcro.

TIP: Your graphic and kick plate should be loose enough to gently slide and shift your graphic over to center in place, if needed. Velcro/magnetic adjustments may be needed to complete a smooth finish.

5. Place counter top onto top of case securing with velcro. Try not to move podium once all set up.



Back side of podium
when set up

To Reposition -

Roll graphic back up to starting point, adjust, then roll back out.

NOTE: DO NOT KINK OR USE ROUGH TREATMENT

